



# Portable Pop Up MARQUEES

## SAFETY INFORMATION

- ONLY USE THE SUPPLIED PUMP
- MAKE SURE ALL PARTS ARE SECURED CORRECTLY DURING ASSEMBLY
- DO NOT OPEN THE ZIPPER WHILE THE FLAGPOLE IS INFLATED
- KEEP AWAY FROM SHARP OBJECTS

TOP ANCHOR

MAST

FLAG

ZIP

BOTTOM ANCHOR

RED CAP VALVE

BASE STRAPS

BASE ANCHOR





# Portable Pop Up MARQUEES

1



Lay out all Giant Inflatable Flag parts and ensure all Red Cap Valves and Black Cap Valves are fastened and airtight.

2



Line the Mast and Flag Zip up and attach the Flag onto the Mast (top to bottom).

3



Attach the Mast Fastening Straps to the Top Anchors and inflate the Mast through the Black Cap Valve using the provided pump.

4



Clip the Short Buckle Straps to the ends of the Mast Fastening Straps.

5



Fill the base with a maximum of 20 litres of water through one of the Red Cap Valves at the top of the Base, then disconnect hose. Fasten the valve when finished.

6



Ensure the Black Cap Valve is on the top-side of the base, then attach your air pump and inflate until the base is tight. Fasten the valve when finished.

7



Ensure the Base is the correct way up, with Red Cap Valves on the top. Push the Mast into the centre hole of the Base.

8



Tie the Base Straps to the mast Base Anchors, ensuring all straps are tight.

9



Put your Ground Stakes through the metal loops on the underside of the Base, and secure Mast Fastening Straps to the Ground Stakes via loops on the ends of the Short Buckle Straps.

## DISASSEMBLY

1. PULL OUT GROUND STAKES AND UNHOOK FROM FASTENING STRAPS.
2. REMOVE MAST FROM BASE.
3. DETACH ALL FASTENING STRAPS FROM MAST.
4. OPEN ALL VALVES AND ROLL THE MAST (TOP TO BOTTOM) TO PUSH AIR OUT.

5. UNZIP FLAG FROM DEFLATED MAST.
6. OPEN ALL VALVES ON THE BASE TO LET AIR AND WATER OUT.
7. PRESS GENTLY ON THE TOP OF THE BASE TO DRAIN AIR AND WATER - (DO NOT STAND OR SIT ON BASE WHILE DRAINING).